

HAUPTMENÜ - AUTOMATIKBETREIB

HAUPTMENÜ – MANUELLER BETRIEB



LICHT
 HEIZEN / KÜHLEN

SONNEN-SCHUTZ
 BELEGT: Automatik / Manuell



← Manueller Modus aktiviert


BELEUCHTUNGS-MENÜ → → →

BELEUCHTUNGS EINSTELLUNG



LICHT FENSTER-ZONE
 Zurück zum Hauptmenü

LICHT RAUM-ZONE




AB-DIMMEN
 Zurück zum Hauptmenü

AUF-DIMMEN
 EIN / AUS

VERSCHATTUNGS-MENÜ → → → Bei mehr als einem Sonnenschutz

VERSCHATTUNGS EINSTELLUNG



SONNEN-SCHUTZ OST
 Zurück zum Hauptmenü


SONNEN-SCHUTZ SÜD



ABWÄRTS
 Zurück zum Hauptmenü

AUFWÄRTS

HEIZEN / KÜHLEN



KÜHLEN
 Zurück zum Hauptmenü

HEIZEN
 Aktuelle Temperatur

MAIN MENU – AUTOMATIC MODUS

MAIN MENU – MANUAL MODUS

LIGHT

SHADING

HEATING / COOLING

MODUS:
Automatic /
Manual



LIGHT

SHADING

HEATING / COOLING

← manual
modus
activated



LIGHTING MENU



LIGHTING SETTING

LIGHT WINDOW-ZONE

LIGHT ROOM-ZONE

Back to main menu




DIM DOWN

DIM UP

Back to main menu

ON / OFF



SHADING MENU




SHADING SETTING

In case of more than one shading

SHADING EAST

SHADING SOUTH

Back to main menu



DOWN

UP

Back to main menu



HEATING / COOLING

COOLING

HEATING

Back to main menu

Current temperature

